

## PARCEL DOOR LOCK INSTALLATION:

1. INSERT (4) #PH 0800006 1/4"-20 x 1 1/4" 18-8 S/S CARRIAGE BOLTS INTO DOOR.
2. SLIP ARROW LOCK AND SPACER #4-40405 OVER CARRIAGE BOLTS AND APPLY (4) #PH 4100014 1/4"-20 S/S NYLOK NUTS AND TIGHTEN.
3. NEXT SLIDE #4-40407 PARCEL ARROW LOCK COVER OVER ASSEMBLY SO SMALL TAB ON COVER SLIPS INTO CUTOUT ON DOOR AND INSERT (1) #PH 8900002 #10-32 x 5/16" MCGARD SCREW.
4. PLACE #4-40406 PARCEL 910 LOCK COVER ONTO ASSEMBLY AND INSERT (2) #PH 8900001 #10-32 x 3/8" S/S TAMPER RESISTANT SCREWS.

